EMP Note:
Create a C project in CoIDE.

Select: <Project><New Project>:

Chose a Project Name, a Project Path and push <Next>:

Select: "Model based on chip" and push <Next>:

Select: "TI/LM3S6000/LM3S6965" and push <Finish>.

Morten Hansen
moh@mmmi.sdu.dk

Check the "BOOTLOADER startupcode" in the Repository panel.

Now, select: "View/Configuration/compile" and add an Includepath to your lm3s6965.h file.

Finally configure your target hardware by selecting: "View/Configuration/Debugger". Choose Adapter = "Stelaris-ICDI".

Now you are ready to code.

Good luck,
Morten

Morten Hansen
moh@mmmi.sdu.dk